

Getting Started Guide

Suggested AppleTV settings after PoolSide/SideLine Live App Installed

(If you purchased your AppleTV from us these configuration settings will be already applied)

Turn Off Screen ScreenSaver, otherwise it may activate in the middle of practice

- Go to the Apple TVs **Settings**  -> **General** -> **Screen Saver** -> **Start After** -> **Never**


Turn off the Sleep, otherwise it may activate in the middle of practice

- Go to the Apple TVs **Settings**  -> **General** -> **Sleep After** -> **Never**


End of Practice

Exit the SideLine/PoolSide Live app by returning to App home screen and pressing the menu or back button until prompted to Close App. Once you reach the AppleTV home screen you can press the menu or back button on the remote until screensaver activates to eliminate potential screen burn in.


APPLE TV REMOTE FUNCTIONS













The previous Menu button is now a back arrow on the new AppleTV remotes.



VIDEO PLAYER TOOLBAR FUNCTIONS



- **SHOW/HIDE PLAYER TOOLBAR:** Swipe down on the Apple TV remote to make the Player Toolbar appear or disappear
- When the Player Toolbar is hidden **REMOTE GESTURES** on the touch pad are available (See Remote Illustration)

<u>PLAYER TOOLBAR</u>	<u>ACTION</u>	<u>APPLE REMOTE GESTURE</u>
 Slow	SLOW MOTION	Long Press & Hold on Touchpad
 Jump	JUMP BACK	Swipe Left on Touchpad while Video Playing
 Jump	JUMP FORWARD	Swipe Right on Touchpad while Video Playing
 Rewind	REWIND (Progressive)	Not Applicable
 Play Pause	PLAY/PAUSE	Press/Click Touchpad
 Fast	FAST FORWARD (Progressive)	Not Applicable
 Step	STEP BACKWARD (Frame by Frame)	Swipe Left on Touchpad while Video Paused
 Step	STEP FORWARD (Frame by Frame)	Swipe Right on Touchpad while Video Paused
 15 Sec	CLIP VIDEO (Requires Wi-Fi Network)	Not Applicable
 Go Live	GO LIVE (Return to Preset Delay)	Swipe Up on Touchpad

PLAYER TOOLBAR FUNCTIONS (Cont'd)

VIDEO CLIPPING TOOL (Wi-Fi Network Required)

This feature allows you to take short clips from the live session and download to your iPad/iPhone.

- Press scissors icon to clip the last (x) seconds (based on your default clip setting range from 5sec - 5min)
- Press and hold the scissor icon to change the clip length on demand.
- QR Code will appear in bottom right corner immediately after processing and is available for download by scanning QR Code. Clips can also be access from recordings after the session is complete.
- Internet connectivity is suggested but not required. This will aid in the ability to quickly and easily share video clips via social media or other apps.



If the QR Code disappears with the control bar, simply swipe down and you can retrieve those clips again or you can find the clippings under the Recordings tab at the top of the that page.



Coach/Athlete must have the SideLine Scout Viewer App(iPhone/iPad) for QR code to download clip

Select the QR button  on the top bar in the SideLine Scout Viewer to scan the code on your TV screen

iPad/iPhone must be connected to the same Wi-Fi network as the AppleTV to download the clip.

How to Hot Swap between 2 cameras

- When running a split screen you can choose to watch a specific camera in full screen by press the Split icon on the toolbar then selecting the camera you want full screen.
- When in full screen mode you can quickly switch between the 2 cameras by double tapping the touch pad on your remote.

How to get back to Main Screen

- Press the MENU button or back button on your Apple TV remote
- Select the Stop Recording or Stop All Recordings(When in Split Screen Mode) button to go back to the main screen

MAIN APP FUNCTIONS - HOW TO

SET ORIENTATION (*Landscape/Portrait*)

- Select Settings
- Select TV Orientation to toggle between Landscape, Portrait, and Flipped Portrait

FIND/SCAN FOR CAMERAS

- From the Main select Find Cameras
- Scan will begin looking for cameras on the connected network

MANUALLY ADD A CAMERA

- From the Main select ADD CAMERA
- Enter the IP Address for the camera
- Select Done
- If Camera is Found it will be added, if not select Add Anyways to add

DELETE A CAMERA

- On Main Page highlight camera you would like to Remove
- Press and hold touchpad on remote until camera menu is visible
- Select Delete
- Confirm Delete

REORDER CAMERAS

- Long press the touchpad on the Apple TV remote on a specific camera
- Select Reorder
- Camera is now movable to the right or left to switch the order on the main page

CLONE CAMERA

- Long press the touchpad on remote for specific camera
- Select Clone
- Camera now has a clone the main page and will be named with a copy, then copy 2 with a 2nd clone and copy 3 with a 3rd clone

HIDE CAMERA

- Long press the touchpad on remote for specific camera
- Select Hide
- Camera is now hidden from the main page
- Repeat this process but select *unhide* to make it visible again on the main page

CHANGE CLIP LENGTH

- Go to the Settings tab at the top of the screen, select clip length and adjust to the clipping range of your choice from 5 seconds to 5 minutes.

CHANGE THE JUMP BACK DISTANCE

- Select Settings
- Select Jump Back Distance (in Seconds)
- Enter the number of seconds for the Jump Back Distance and select DONE. Select Save to finalize changes
- Select Save to finalize changes

VIEW PAST SESSIONS

- From the Main Page select Recordings
- Scroll to select the correct Session
- Short press on the touchpad to select session to play

PROTECT A SESSION FROM BEING DELETED

- From the Main Page select Recordings
- Press and hold the touchpad on the Apple TV Remote until the menu is visible
- Select Protect from the menu
- The app will now not delete the videos within this session when performing cleanup maintenance when additional space is needed for future recordings

UNPROTECT A SESSION TO BE DELETED

- From the Main Page select Recordings
- Press and hold touchpad on remote until the menu is visible
- Select Unprotect from the menu
- This session is now available to be deleted when performing cleanup maintenance when additional space is needed for future recordings

RENAME A RECORDED SESSION

- From the Main Page select Recordings
- Press and hold touchpad on Remote until the menu is visible
- Select Rename Session from the menu
- Enter the new name for the session and select Done

CAMERA SETTINGS

BASIC

CAMERA NAME *Changing a Camera's Name*

- From the Main Page highlight the camera you would like to Change the Name
- Press and hold the touchpad on the Apple TV Remote until the camera menu is visible
- Select Basic Settings
- Select Camera Name
- Enter the new name you want and select Done
- Select Save to finalize changes

CAMERA DELAY *To change a Camera's Delay press Menu button on remote while watching the active video stream or long press on touchpad of the remote while selecting the camera from Main Screen*

- Select Basic Settings
- Select Camera Delay (in Seconds)
- Enter the number of seconds for delay and select DONE
- Select Save to finalize change

CAMERA GRID *Show / Hide Grid*

- When in a camera view press the MENU button on the Apple TV remote
- Select Show Grid to display a grid over your camera view
- Select Hide Grid to remove the grid

ADVANCED

IP ADDRESS *Changing the Camera's IP Address*

- From the Main Page highlight the camera you would like to change the IP Address for
- Press and hold the touchpad on the Apple TV Remote until the camera menu is visible
- Select Advanced Settings
- Select IP Address
- Enter the new IP Address and select Done
- Select Save to finalize changes

PATH *Setting the Path on a Camera*

- From the Main Page highlight the camera you would like to Set the Path for
- Press and hold the touchpad on the Apple TV Remote until the camera menu is visible
- Select Advanced Settings
- Select Path
- Enter the path for the camera and select Done
- Select Save to finalize changes

STREAM TYPE *Changing the Stream Type of a Camera*

- From the Main Page highlight the camera you would like to Change the Stream Type for
- Press and hold the touchpad on the Apple TV Remote until the camera menu is visible
- Select Advanced Settings
- Select Stream Type
- Select either RTSP, RTMP or HTTP
- Select Save to finalize changes

USERNAME & PASSWORD *If your camera requires authentication to access this is where you put the user/pass*

- From the Main Page highlight the camera you would like to Set a Username and Password for
- Press and hold the touchpad on the Apple TV Remote until the camera menu is visible
- Select Advanced Settings
- Select Username or Password
- Enter Username or Password and select Done
- Select Save to finalize changes

CAMERA SETTINGS WHILE RECORDING

CAMERA ORIENTATION

- Press the MENU button on your remote to bring up the Camera Settings
- Select Basic Settings
- Scroll down to Camera Rotation and choose a new orientation
- Select a degree of rotation 0, 90, 180 or 270

CAMERA PRESET *Supported Cameras (Axis & Amcrest PTZs)*

- Press the MENU button on your remote to bring up the Camera Settings
- Select Camera Presets
- Choose a preset
- Long press touchpad on a preset to rename it

CAMERA DELAY *Change a Camera's Delay*

- Press the MENU button on your remote to bring up the Camera Settings
- Select Basic Settings
- Select Camera Delay
- Enter new delay and select done

ZOOM/PAN

- While in a camera view press the MENU button on your remote
- Scroll down to Zoom / Pan
- Follow instructions on screen to control the camera view.
- PRESS the MENU button to save your settings

SHOW REMOTE CONTROL SWIPE GESTURES

- Press the MENU button on your remote to bring up the Camera Settings
- Select Show Remote Control Gestures

CAMERA GRID *Show / Hide Grid*

- Press the MENU button on your remote to bring up the Camera Settings
- Select Basic Settings
- Select Camera Grid. This will toggle On and Off.
- Select Close

SPLIT SCREEN FUNCTIONS

SPLIT SCREEN VIEW

- From the main screen select the Split Screen button in the middle of the screen
- Select which camera views you would like to have for Camera 1 and Camera 2 (If you want to have the same cameras with different delays we recommend using the clone feature)
- Select the Start Session button. *Each camera's settings can be individually accessed by pressing the MENU button on the Apple TV remote
- You can return to a single camera at any time by pressing the MENU button on your remote and selecting Camera Settings.....Single Camera View

SWITCH BETWEEN CAMERAS ON SPLIT SCREEN

While in split screen view

- On control bar, press split screen button
- Select the main camera you want to see
- Double tap touch pad on remote to switch between both cameras/toggle between both
- To return to split screen, swipe down and select split screen button again

CHANGE SPLIT SCREEN VIEW

Side by Side or Top/Bottom

- When in split screen view press MENU button
- Select Change View to "Top to Bottom" or to "Side by Side"

CONNECTING CAMERA DIRECTLY TO APPLE TV

If you are connecting an Apple TV directly to a camera via network cable you need to set a static IP Address.

1. From the Apple TV main screen under Settings
2. Select Network
3. Select Ethernet. If it doesn't say Ethernet, then it's not recognizing your cable is plugged in. Make sure your cable is plugged in and your camera has power. Then restart your Apple TV and repeat
4. Select Configure IP and select Manual and enter the IP information to complete the settings
 - a. If you are using one of our pre-configured cameras, then you need to set your Apple TV IP Address to the following:
 - i. IP Address 10.10.10.46
 - ii. Subnet Mask 255.255.255.0
 - iii. Router 10.10.10.1
 - iv. DNS 8.8.8.8

CONNECTING PRE-CONFIGURED WISP TO LIVE SYSTEM

1. After connecting power to the new router, using an ethernet cable plug one end into the middle port of the Wi-Fi router then the other end into any port on your switch/network. This will now allow any iPad/iPhone connected to the SideLineLive Wi-Fi network to download clips using the QR codes directly from the AppleTV.

Continue on if the facility has internet and you want the SideLine Live network to have internet access for updates and easy access to post on social media or share video clips.

2. Connect your phone or laptop to the SideLineLive wireless network and open your internet browser to 10.10.10.1. Login to the admin interface using pre-configured password sls12345. If that doesn't work reference the sticker on the device.
3. If internet is available in the facility, you can connect this new router using the repeater function under the internet section of the admin interface. Reference doc found here [Repeater - GL.iNet Docs \(gl-inet.com\)](#)
4. Go to Internet->Repeater->Scan Now/Connect
5. Find the facility internet in the list. If it requires a password enter it here.
6. Be sure the Remember radio button is selected.
7. Press Apply to connect to the Wi-Fi network.
8. After successful connection you should see the wireless network with a small green dot to the left. Test it out.

Online Doc for this router for additional advanced info: [Homepage - GL.iNet Docs \(gl-inet.com\)](#)

USING POOLSIDE LIVE WITH JUST AN iPhone

How to run PoolSide/SideLine Live with just my iPhone if I DO NOT have an existing network

View this video for instructions: <https://youtu.be/3Ad0Rat6Rdc>

1. Install PoolSide Live on the Apple TV
2. Download an iPhone app that will turn your phone into an RTSP camera. In my example I will use [Live-Reporter \(FREE version\)](#)
3. If you don't have an existing Wi-Fi network there is a little trick you can do to still make it work in a pinch. Open Settings on your iPhone and choose Cellular. In here you will find an option to create a Personal Hotspot. Turn it on and set a password to keep unwanted people from connecting. Your iPhone should now be broadcasting a Wi-Fi network. Now connect your Apple TV to this new hotspot you created (usually set to iPhone by default)
 - a. Open the Settings app on the Apple TV
 - b. Select Network
 - c. Select Wi-Fi
 - d. Wait for nearby networks to appear
 - i. I see my iPhone in the list
 1. Select your iPhone hotspot Wi-Fi name from the list
 2. Type in password for your hotspot Wi-Fi
 - ii. I don't see my iPhone in the list
 1. Select Other
 2. Enter the name of the Wi-Fi network you want to join
 3. Enter the password associated with the network
 4. Click Continue and this should complete the connection
 - e. Press Menu to return to Main AppleTV Screen
4. Launch the Live-Reporter app on your iPhone
5. Next open PoolSide Live on the Apple TV and scan for new cameras. Your iPhone IP should show up in the grid after the scan is complete. If it doesn't show up after the scan, make sure the Live-Reporter app is open and you can see your camera video on the screen. The IP address it is using to serve the video to PoolSide Live is displayed and looks something like rtsp://192.168.1.102
6. Once the Camera shows up in the grid select it and start using PoolSide Live. When using an iPhone or iPad as a camera we strongly recommend it be stationary to get the best picture due to the Wi-Fi connectivity.

Thank You

for purchasing this GameDay Edge product

Questions or Concerns?

Please contact SideLine Scout at 918-777-3794

Visit us online at www.sidelinescout.com

Tag us on Twitter, Instagram or Facebook when you post videos

[@SideLineScout](https://twitter.com/SideLineScout)